

Hydraulic Pump Parts

Parker Series



SH5V/131 Parker hydraulic spare parts



PV29/PV74/PVG130B/PVT38, Parker hydraulic spare parts



PARKER 2145/P2145
PARKER 23/P2075/PARKER 270/PV270/P2105/P2060



PAVC38/PAVC65/PAVC100 Parker hydraulic spare parts



BMHQ30/PV180 Parker hydraulic spare parts



PVM-018/PVM-028 Parker hydraulic spare parts



PVXS130/180/250/O250/PV1 PARKER Hydraulic Spare Parts



VOLVO/F11-005~250/F12-060/080/110-MF-1H Parker hydraulic spare parts

Hydraulic Pump Parts

Komatsu Excavator Series



| ITEM | DESCRIPTION | QUANTITY |
|------|-------------------|----------|
| 1 | VALVE PLATE MOTOR | 1 |
| 2 | CYLINDER BLOCK | 1 |
| 3 | BALL GUIDE | 1 |
| 4 | PISTON SHOE | 7 |
| 5 | RETAINER PLATE | 1 |
| 6 | SWASH PLATE | 1 |
| 7 | SUPPORT | 1 |

PC400-7 TRAVEL MOTOR
KOMATSU



| ITEM | DESCRIPTION | QUANTITY |
|------|-------------------|----------|
| 1 | VALVE PLATE MOTOR | 1 |
| 2 | SUPPORT | 1 |
| 3 | WASHER | 2 |
| 4 | BALL GUIDE | 1 |
| 5 | PISTON SHOE | 1 |
| 6 | SEPARATOR PLATE | 4 |
| 7 | PISTON SHOE | 1 |
| 8 | BALL GUIDE | 1 |
| 9 | PISTON SHOE | 8 |
| 6 | RETAINER PLATE | 1 |
| 5 | SWASH PLATE | 1 |

PC200-7 TRAVEL MOTOR
KOMATSU



| ITEM | DESCRIPTION | QUANTITY |
|------|-----------------|----------|
| 1 | VALVE PLATE | 1 |
| 2 | CYLINDER BLOCK | 1 |
| 3 | RETAINER PLATE | 1 |
| 4 | PISTON | 1 |
| 5 | CENTER PIN | 1 |
| 6 | DRIVE SHAFT | 1 |
| 7 | PISTON SHOE | 3 |
| 8 | SEPARATOR PLATE | 4 |

PC200-6/PC450/LMF45/HPV220-8
SWING MOTOR



| ITEM | DESCRIPTION | QUANTITY |
|------|-----------------|----------|
| 1 | VALVE PLATE | 1 |
| 2 | CYLINDER BLOCK | 1 |
| 3 | PISTON | 7 |
| 4 | RETAINER PLATE | 1 |
| 5 | SEPARATOR PLATE | 1 |
| 6 | SEPARATOR PLATE | 4 |
| 7 | FRICITION PLATE | 3 |
| 8 | DRIVE SHAFT | 1 |
| 9 | CONTROL VALVE | 1 |

PC120-6 SWING MOTOR
KOMATSU



| ITEM | DESCRIPTION | QUANTITY |
|------|-----------------|----------|
| 1 | VALVE PLATE | 1 |
| 2 | LOCK SPRING | 2 |
| 3 | PISTON SHOE | 1 |
| 4 | SEPARATOR PLATE | 4 |
| 5 | SEPARATOR BLOCK | 1 |
| 6 | PRESSURE PIN | 2 |
| 7 | BALL GUIDE | 1 |
| 8 | PISTON SHOE | 7 |
| 9 | RETAINER PLATE | 1 |
| 10 | PISTON SHOE | 7 |
| 11 | RETAINER PLATE | 1 |
| 12 | THRUST PLATE | 1 |
| 13 | DRIVE SHAFT | 1 |

PC45R-8/50-7 SWING
MOTOR KOMATSU



| ITEM | DESCRIPTION | QUANTITY |
|------|-----------------|----------|
| 1 | VALVE PLATE | 1 |
| 2 | CYLINDER BLOCK | 1 |
| 3 | BALL GUIDE | 1 |
| 4 | PISTON SHOE | 9 |
| 5 | RETAINER PLATE | 1 |
| 6 | SWASH PLATE | 1 |
| 7 | SAFETY BEARINGS | 1 |
| 8 | VANE PISTON | 1 |

KOMATSU-PC320



| ITEM | DESCRIPTION | QUANTITY |
|------|------------------|----------|
| 1 | VALVE PLATE | 1 |
| 2 | CYLINDER BLOCK | 1 |
| 3 | SPRING | 1 |
| 4 | WASHER | 1 |
| 5 | CENTER PIN | 1 |
| 6 | CENTER BALL | 1 |
| 7 | PISTON | 7 |
| 8 | RETAINER PLATE | 1 |
| 9 | SPHERICAL WASHER | 7 |
| 10 | DRIVE SHAFT | 1 |

PC200-2/PC60-6



| ITEM | DESCRIPTION | QUANTITY |
|------|----------------|----------|
| 1 | VALVE PLATE | 1 |
| 2 | CYLINDER BLOCK | 1 |
| 3 | BALL GUIDE | 1 |
| 4 | RETAINER PLATE | 1 |
| 5 | PISTON SHOE | 9 |
| 6 | SWASH PLATE | 1 |
| 7 | SUPPORT | 1 |
| 8 | DRIVE SHAFT | 1 |

KOMATSU-PC160



| ITEM | DESCRIPTION | QUANTITY |
|------|----------------|----------|
| 1 | VALVE PLATE | 1 |
| 2 | SPRING | 1 |
| 3 | CYLINDER BLOCK | 1 |
| 4 | PRESSURE PIN | 3 |
| 5 | BALL GUIDE | 1 |
| 6 | RETAINER PLATE | 1 |
| 7 | PISTON SHOE | 70L |
| 8 | SWASH PLATE | 1 |
| 9 | DRIVE SHAFT | 1 |

PC40-6/PC60-7



| ITEM | DESCRIPTION | QUANTITY |
|------|----------------|----------|
| 1 | VALVE PLATE | 1 |
| 2 | SHAFT RING | 1 |
| 3 | WASHER | 2 |
| 4 | COIL SPRING | 1 |
| 5 | CYLINDER BLOCK | 1 |
| 6 | BALL GUIDE | 1 |
| 7 | RETAINER PLATE | 1 |
| 8 | PISTON SHOE | 7 |
| 9 | SWASH PLATE | 1 |

PC30LUU



| ITEM | DESCRIPTION | QUANTITY |
|------|------------------|----------|
| 1 | VALVE PLATE | 1 |
| 2 | VALVE PLATE RING | 1 |
| 3 | CYLINDER BLOCK | 1 |
| 4 | PRESSURE PIN | 5 |
| 5 | BALL GUIDE | 1 |
| 6 | PISTON SHOE | 15 |
| 7 | RETAINER PLATE | 2 |
| 8 | SWASH PLATE | 2 |
| 9 | SWASH PLATE | 10 |
| 10 | SUPPORT | 1 |
| 11 | SUPPORT GEAR | 1 |
| 12 | DRIVE SHAFT | 1 |
| 13 | DRIVE SHAFT GEAR | 1 |
| 14 | CHANGE RING | 1 |

HPV95/132/PC360-7/PC200-8/240-8/PC1250



| ITEM | DESCRIPTION | QUANTITY |
|------|-----------------|----------|
| 1 | VALVE PLATE | 1 |
| 2 | CYLINDER BLOCK | 1 |
| 3 | RETAINER | 2 |
| 4 | SPACER | 2 |
| 5 | PRESSURE PIN | 1 |
| 6 | BALL GUIDE | 1 |
| 7 | SEPARATOR PLATE | 1 |
| 8 | SWASH PLATE | 0 |
| 9 | SWASH PLATE | 1 |
| 10 | SUPPORT | 1 |
| 11 | DRIVE SHAFT | 1 |
| 12 | CHARGE PUMP | 1 |
| 13 | MAIN SHAFT | 1 |
| 14 | SHAFT | 1 |

HPV35/HPV55/HPV90/HPV107

Hydraulic Pump Parts

Hitachi Series



| ITEM | DESCRIPTION | QUANTITY |
|------|------------------|----------|
| 1 | VALVE PLATE | 1 |
| 2 | CYLINDER BLOCK | 1 |
| 3 | SEPERATION PLATE | 3 |
| 4 | PISTON SHOE | 4 |
| 5 | SPRING | 6 |
| 6 | BALL GUIDE | 1 |
| 7 | PISTON SHOE | 9 |
| 8 | RETAINER PLATE | 1 |
| 9 | SWASH PLATE | 1 |
| 10 | DRIVE SHAFT | 1 |

ZX330-2 TRAVEL MOTOR



| ITEM | DESCRIPTION | QUANTITY |
|------|-------------------|----------|
| 1 | VALVE PLATE MOTOR | 1 |
| 2 | SPRING | 1 |
| 3 | COIL SPRING | 1 |
| 4 | WASHER | 2 |
| 5 | CYLINDER BLOCK | 1 |
| 6 | PISTON SHOE | 1 |
| 7 | PISTON SHOE | 9 |
| 8 | SPRING | 1 |
| 9 | DRIVE SHAFT | 1 |
| 10 | DRIVE SHAFT | 1 |
| 11 | SWASH PLATE | 1 |
| 12 | PISTON SHOE | 2 |
| 13 | PISTON SHOE | 2 |
| 14 | PISTON SHOE | 2 |
| 15 | PISTON SHOE | 2 |

HMF160/200



| ITEM | DESCRIPTION | QUANTITY |
|------|-------------------|----------|
| 1 | VALVE PLATE MOTOR | 1 |
| 2 | PISTON SHOE | 3 |
| 3 | SEPERATION PLATE | 4 |
| 4 | CYLINDER BLOCK | 1 |
| 5 | SPRING | 6 |
| 6 | BALL GUIDE | 1 |
| 7 | PISTON SHOE | 9 |
| 8 | RETAINER PLATE | 1 |
| 9 | SWASH PLATE | 1 |

HMGE36EA ZX200 TRAVEL MOTOR



| ITEM | DESCRIPTION | QUANTITY |
|------|-------------------|----------|
| 1 | VALVE PLATE MOTOR | 1 |
| 2 | CYLINDER BLOCK | 1 |
| 3 | BALL GUIDE | 1 |
| 4 | RETAINER PLATE | 1 |
| 5 | PISTON SHOE | 9 |
| 6 | SWASH PLATE | 1 |
| 7 | DRIVE SHAFT | 1 |

EX550-3 TRAVEL MOTOR



| ITEM | DESCRIPTION | QUANTITY |
|------|------------------|----------|
| 1 | VALVE PLATE | 1 |
| 2 | CYLINDER BLOCK | 1 |
| 3 | SPRING | 1 |
| 4 | PISTON | 7 |
| 5 | CENTER PIN | 1 |
| 6 | FRUCTION PLATE | 3 |
| 7 | SEPERATION PLATE | 2 |
| 8 | DRIVE SHAFT | 1 |

HMGC16/32/35



| ITEM | DESCRIPTION | QUANTITY |
|------|-------------------|----------|
| 1 | VALVE PLATE MOTOR | 1 |
| 2 | SWASH PLATE | 1 |
| 3 | WASHER | 1 |
| 4 | COIL SPRING | 1 |
| 5 | WASHER UP | 1 |
| 6 | CYLINDER BLOCK | 1 |
| 7 | BALL GUIDE | 1 |
| 8 | RETAINER PLATE | 1 |
| 9 | PISTON SHOE | 9 |
| 10 | DRIVE SHAFT | 1 |

EM56 TRAVEL MOTOR



| ITEM | DESCRIPTION | QUANTITY |
|------|-------------------|----------|
| 1 | VALVE PLATE MOTOR | 1 |
| 2 | CYLINDER BLOCK | 1 |
| 3 | BALL GUIDE WASHER | 4 |
| 4 | BALL GUIDE | 1 |
| 5 | RETAINER PLATE | 1 |
| 6 | PISTON SHOE | 9 |
| 7 | THRUST PLATE | 1 |

ZAX120 SWING MOTOR



| ITEM | DESCRIPTION | QUANTITY |
|------|----------------|----------|
| 1 | VALVE PLATE | 1 |
| 2 | CYLINDER BLOCK | 1 |
| 3 | BALL GUIDE | 1 |
| 4 | PISTON SHOE | 9 |
| 5 | RETAINER PLATE | 1 |
| 6 | DRIVE SHAFT | 1 |

EX105-2 MOTOR/EX120-2 SWING MOTOR



| ITEM | DESCRIPTION | QUANTITY |
|------|-------------------|----------|
| 1 | VALVE PLATE MOTOR | 1 |
| 2 | CYLINDER BLOCK | 1 |
| 3 | BALL GUIDE | 1 |
| 4 | PISTON SHOE | 9 |
| 5 | RETAINER PLATE | 1 |

EX60-2/3 SWING MOTOR



HPV125A/B



HPV116/145/125B



HPV091 EX200-2/3 EX120-2 PUMP

Hydraulic Pump Parts

Rexroth Series



| ITEM | DESCRIPTION | QUANTITY |
|------|-----------------|----------|
| 1 | SWASH PLATE LIN | 1 |
| 2 | SWASH PIN | 1 |
| 3 | SPRING | 1 |
| 4 | SWASH | 2 |
| 5 | CYLINDER BLOCK | 1 |
| 6 | PRESS PIN | 3 |
| 7 | BALL GUIDE | 1 |
| 8 | PISTON SHOCK | 10 |
| 9 | RETURN PLATE | 1 |
| 10 | TRUCK PLATE | 1 |
| 11 | SWASH PLATE | 1 |
| 12 | ROTOR SHAFT | 1 |

ap2d12-36zx70 main pump
rexroth hydraulic pump
parts



Rexroth Series Hydraulic
Pump A11VO Parts With
Spare Parts Repair Kit



Rexroth Series Hydraulic
Pump A10VSO Parts With
Spare Parts Repair Kit



Rexroth Series Hydraulic
Pump A8VO Parts With
Spare Parts Repair Kit



Rexroth Series Hydraulic
Pump A7VO Parts With
Spare Parts Repair Kit



Rexroth Series Hydraulic
Pump A6VM Parts With
Spare Parts Repair Kit



Rexroth Series Hydraulic
Pump A4VG Parts With
Spare Parts Repair Kit



Rexroth Series Hydraulic
Pump A2FM Parts With
Spare Parts Repair Kit

Hydraulic Pump Parts

Sauer Danfoss Series



BRL100 SAUER 90 Hydraulic Replacement Spare Parts



HRR057 SAUER 90 Hydraulic Replacement Spare Parts



MPT044/M44 SAUER 90 Hydraulic Replacement Spare Parts



SPV14/SPV15/SPV18/MMFO SAUER 90 Hydraulic Parts



PV90R0/30/42/55/75/100/13 SAUER 90 Hydraulic Replacement Spare Parts



SAUER MPV45 Hydraulic Pump Parts



SAUER MPR63 Hydraulic Pump Parts



SAUER MPV046/M46 Hydraulic Pump Parts



SAUER MF16A/MF035/MF500 Hydraulic Pump Parts



SAUER PVD45/TB35/45 Hydraulic Pump Parts



PV PVD SPV OPV 20 21 22 23 24 27 119 112 Sauer Hydraulic Pump Parts



Sauer Danfoss Series Hydraulic Pump PV42 Parts With Spare Parts Repair Kit



Hydraulic Pump Parts

Uchida Series

Uchida Series Hydraulic Pump A8V55 Parts With Spare Parts Repair Kit





Hydraulic Pump Parts

Messori Series

Messori Series Hydraulic Pump ARK90 Parts With Spare Parts Repair Kit



SAIVS

Hydraulic Pump Parts

Kayaba Series

Kayaba Series Hydraulic Pump PSVD2 Parts With Spare Parts Repair Kit





Hydraulic Pump Parts

Toshiba Series

Toshiba Series Hydraulic Pump PVC80 Parts With Spare Parts Repair Kit





Hydraulic Pump Parts

Nachi Series

Nachi Series Hydraulic Pump PVD Parts With Spare Parts Repair Kit



Hydraulic Pump Parts

Eaton Vickers Series



PVQ40/50 EATON-VICKERS
Hydraulic Replacement
Spare Parts



EATON-VICKERS
PVB5/PVB6/PVB10/PVB15/PV
SR/PVB110



EATON-VICKERS Model
PVH45/PVH57/PVH74/PVH8
1398)/PVH131/PVH141



PVE19/PVE21/TA19 EATON-
VICKERS Hydraulic
Replacement Spare Parts



EATON Model
006/3322/3932-
243/4621/4631-
007/5421/5431/6423/7621/7



Eaton Vickers Series
Hydraulic Pump PVE Parts
With Spare Parts Repair Kit

Hydraulic Pump Parts

Linde Series



BMF50/BMF75/BMF105
LINDE Hydraulic
Replacement Spare Parts



BPR140/186/260 LINDE
Hydraulic Replacement
Spare Parts



BMV75.27 LINDE Hydraulic
Replacement Spare Parts



BPV35/BPV50/BPV70/BPV100
LINDE Hydraulic
Replacement Spare Parts



B2PV35/50/75/105/B2PV140
LINDE hydraulic spare parts



HPV55T/HPR75/HMR135/HP
LINDE hydraulic spare parts

SAIVS

Hydraulic Pump Parts

Caterpillar Series

Caterpillar Series Hydraulic Pump CAT12G Parts With Spare Parts Repair Kit



Hydraulic Pump Parts

Kawasaki Series



TM40VD TRAVEL MOTOR
Kawasaki Hydraulic Pump
Parts



LZV30/120/LVWO60
Kawasaki Hydraulic Pump
Parts



MAG150/170 KAWASAKI
SWING MOTOR



MX150/MX173/MX500
KAWASAKI SWING MOTOR



M5X130(CAT320C)/M5X180
Kawasaki Hydraulic Pump
Parts



M2X63/96/120/146/150/170
kawasaki swing motor
hydraulic pump parts



Kawasaki NX15/NVK45
Hydraulic Pump Parts



Kawasaki
NV64/NV84/NV111DT/NV13
Hydraulic Pump Parts



Kawasaki K7V63 Hydraulic
Pump Parts



Hydraulic Pump Parts

Kobelco/Kato Series



HYUNDAI 60-7/480
KOBELCO/KATO Hydraulic
Pump Parts



DH55/T3X128/DAEWOO
300-7/DH370 SWING
MOTOR KOBELCO/KATO



HD450V-2 / HD3000
Kobelco/Kato Hydraulic
Pump Parts



Hydraulic Pump Parts

Hawe Series



V30D45/V30D95/V30Z95/V3
HAWA Hydraulic
Replacement Spare Parts



V60A HAWA Hydraulic
Replacement Spare Parts